WOOD/COAL BURNING STOVE SUPPLEMENTAL INSPECTION FORM			Insured's Name				Policy No.
Stove/Furnace Unit	Туре	Open Hearth Pot Belly, E (No doors) CLoose fitting				tting, dra	aft-limiting doors and seams)
	Construction	☐ Sheet Metal	☐ Cast Iron	☐ Brick Lined	Any Cracks or B	roken P	earts? ☐ Yes ☐ No
	Fuel	□Wood□] Coal	Other (specify):			
	Principal Use	☐ Primary Heat Source (More than 50 days/yr.)		☐ Supplemental Heating (Less than 50 days/yr.) ☐ Cooking			oking
σ	Installed By	Owner	☐ Contracto	r ☐ Month/Year of Installation			
	Inspected By	☐ Building Inspector ☐ Fire Department ☐ Other (specify):					
Chimney/Chimney Connector (Stove Pipe)	Installation	Stove placed at least 36" from combustible well or furnishings, or 18" from non-combustible shield with 1" air space to combustible wall.		Non-combustible pad or surface below stove, extends at least 18" beyond loading door and 12" beyond side and rear.		Stove legs allow at least 4" air space below stove.	
		☐ Yes [□ No	☐ Yes	□ No		☐ Yes ☐ No
	Туре	☐ Masonry ☐ U.L. Listed Metal Chimney					
	Cleaned/ Inspected	When last cleaned (Mo./Yr.)		Last inspected (Mo./Yr.)		Are ashes disposed of in a fireproof container? ☐ Yes ☐ No	
	Installation	Passes through non-combustible thimble collar or opening which is at least 12" larger in diameter than stove pipe:		Connector to chimney under 10' in length:		Galvanized steel pipe:	
S		☐ Yes ☐	No	☐ Yes [□ No		☐ Yes ☐ No
		More than two bonds:		Horizontal portion rises at least ¼" per linear ft. of pipe length so chimney connection point is higher than stove end:		Pipe sections overlap to contain creosote flowback:	
		☐ Yes ☐	No	☐ Yes [□ No		☐ Yes ☐ No
ecomm- dations							

